



1. Turn off general switch
2. Drill holes, apply plastic anchors
3. Apply screws
4. Connect the wires & apply the product in to place
5. Apply the side screws
6. Turn on the general switch

