



1. Turn off general switch
2. Drill a holes, apply plastic anchors
3. Apply screws
4. Connect the wires
5. Put it in place & Apply side screws
6. Apply the bulb
7. Apply the crystals
8. Turn on the general switch

