



1. Turn off general switch
2. 3. Align, Drill Holes & Make It Stable
4. Connect The Wires
5. Put It In Place & Apply side Screws
6. Apply The Rattan
7. Screw The plastic
8. By rotating apply the bulb
9. Turn on general switch

