



1. Turn off the general switch
2. Drill holes & apply plastic anchors
3. Tie up screws
4. Connect the wires
5. Fix it in place & apply the side screw
6. Turn on the general switch

