


NOVA LUCE


9236210

1




Turn off the general switch

2




Drill holes & apply plastic anchors
With screws

3




Connect the wires

4




Apply the side screws

5



By rotating apply the glass

6



Turn on the general switch

