



1




Turn off the general switch

2




Untie screws & remove upper part

3




Fix the base on the ground by applying anchors with screws & connect wires

4



Apply side screws

5



Turn on the general switch

6

