


# NOVA LUCE


9248178

1




Turn off the general switch

2




Drill holes, Insert plastic anchors  
& Apply screws

3




Connect the wires

4




Apply the side screws

5




Turn on the general switch



# NOVA LUCE

## Infrared ray Remote control instructions



1. | Switch on the light, keep the memory of last time.
2. ○ Switch off the light.
3. ☀ Brightness +: when the lamp is on, press and hold this button down to increase the brightness.
4. ☀ Brightness -: when the lamp is on, press and hold this button down to increase the brightness.
5. ☀ Color temperature +: hold down this button, color from yellow to white.
6. ☀ Color temperature -: hold down this button, color from white to yellow.
7. ◐ Color temperature switch: Yellow-Warm white-White.
8. 🌙 Nightlight mode: 10% brightness of Yellow light.

### Remark:

The light also can be switched by regular wall switch, the color temperature can be changed if on and off the light within 5 seconds, the sequence:  
Yellow light → Warm white → White → Night light