



Anway TUYA-CW Smart APP operation

1. Download "Smart Life" or "Tuya Smart" application from APP gallery and install in mobile.



2. TUYA-WIFI distribution mode:


First turn on → turn off (wait 5 seconds)
 Second turn on → turn off (wait 5 seconds)
 Third turn on (no need turn off) , Now, you're in the flash network configuration state



3. 2.4G remote control and lamp code-matching mode: After turning on the light, press and hold group 1, or group 2, or the total group, Press and hold 5S. The remote control indicator flashes a few times and the connection is successful.

4. Remote control button description:

- A. " • ": Indicator light (Red)
 B. " NO ": Button "ON"
 C. " OFF ": Button "OFF"
 D. " CCT + ": Gradually increase color temperature and brightness
 E. " CCT - ": Gradually decrease color temperature and brightness
 F. " W ": CCT change (Warm White & Cool White)
 G. " ☀ ": Gradually increase dimming brightness
 H. " ☾ ": Gradually decrease dimming brightness
 I. " MCE ": Workplace light :dimmable 100% or Nightlight :Continuously dimmed to 5 %
 J. " ⌘ ": For CCT 2channels, this button is no function
 K. " 1-2 ": Total Group 1-2
 L. " ① ": Group 1 (Pair : Long press 5seconds ,then indicator light blink 3 times)
 M. " ② ": Group 2 (Pair : Long press 5seconds ,then indicator light blink 3 times)




5. Open tuya smart APP, click "+" on the top right, select "Smart Lighting" on the left column, then click "Lighting Devices", and click "Confirm light blinks rapidly"




6. Enter Wi-Fi password to start the connection.


Remark: If fail to connect, repeat the procedures from point 2.



7. After connected, can control the lamp via the APP.



8. More function CW



select the third party control for voice assistant, such as Amazon Alexa/ Google assistant.

Share the device with family members to set light by different terminals.

Create groups in one house to control different devices by same terminal.


Anway TUYA-CWRGB Smart APP operation

1. Download "Smart Life" or "Tuya Smart" application from APP gallery and install in mobile.



2. TUYA-WIFI distribution mode:


First turn on → turn off (wait 5 seconds)
 Second turn on → turn off (wait 5 seconds)
 Third turn on (no need turn off) , Now, you're in the flash network configuration state



3. 2.4G remote control and lamp code-matching mode: After turning on the light, press and hold group 1, or group 2, or the total group. Press and hold 5S. The remote control indicator flashes a few times and the connection is successful.

4. Remote control button description:

- A. " • ": Indicator light (Red)
 B. " NO ": Button "ON"
 C. " OFF ": Button "OFF"
 D. " CCT + ": Gradually increase color temperature and brightness
 E. " CCT - ": Gradually decrease color temperature and brightness



for RGB CCT 5 channels, Button 6 & 7 will be only working by first pressing Button 13 " ⑧ " then press this button, for example, when you first press the Button 13 " ⑧ " to blue color, then press button CCT+ or CCT-, it is blue light mixes with white light


- F. " W ": CCT change (Warm White & Cool White)
 G. " ☀ ": Gradually increase dimming brightness
 H. " ☁ ": Gradually decrease dimming brightness
 I. " MOON ": Workplace light : dimmable 100% or Nightlight : Continuously dimmed to 5 %
 J. " ⑧ ": for CCT 5 channels, this button is no function
 K. " 1-2 ": Total Group 1-2
 L. " 1 ": Group 1 (Pair : Long press 5 seconds , then indicator light blink 3 times)
 M. " 2 ": Group 2 (Pair : Long press 5 seconds , then indicator light blink 3 times)

4. Open tuya smart APP, click "+" on the top right, select "Smart Lighting" on the left column, then click "Lighting Devices", and click "Confirm light blinks rapidly"




5. Enter Wi-Fi password to start the connection.


Remark: If fail to connect, repeat the procedures from point 2.



6. After connected, can control the lamp via the APP.



7. More function



select the third party control for voice assistant, such as Amazon Alexa/ Google assistant.

Share the device with family members to set light by different terminals.

Create groups in one house to control different devices by same terminal.